

## W. OSTWALDI 1-A111 RUUMITEHNIKA JUHEND

### PROJEKTORI KASUTAMINE:

Lülita puldi **roheline** nupuga projektor sisse.



Sülearvuti ühendamiseks kasutada laua peal olevat **HDMI** või **VGA** kaablit.

**Muid juhtmeid mitte lahti ühendada!!!**

Et valida erinevate sisendite vahel (sülearvuti), tuleb kasutada projektori puldi nuppu **INPUT**. VGA sisend on INPUT A ja HDMI sisend on INPUT C.



Kui sülearvuti pilt mõne aja möödudes pärast nupuvajutust projektorisse ei ilmu, proovida klahvikombinatsiooni:



**Projektor tuleb pärast kasutamist kindlasti välja lülitada, vajutades sedasama rohelist nuppu, mis käivitamisel!**

### PROBLEEMIDE TEKKIMISEL:

Paluda abi Physicumi infosekretäri käest või ühendust võtta Tartu Ülikooli Arvutiabiga.

737 5500 (5500)

[arvutiabi@ut.ee](mailto:arvutiabi@ut.ee)

[www.it.ut.ee](http://www.it.ut.ee)



## W. OSTWALDI 1-A111 EQUIPMENT USAGE INSTRUCTIONS

### USING THE PROJECTOR:

Press the **green** button on the remote to turn on the projector.



You can use the **HDMI** or **VGA** cable on the table to connect your laptop to the projector.

**Do not reorganize any other cables!!!**

To choose from different devices (laptop) use the **INPUT** button on the remote. VGA is INPUT A and HDMI is INPUT C.



If the laptop screen does not appear on the projector after pressing this button and waiting a while, press:



**After using the projector be sure to turn it off by pressing the same green button as used to turn the projector on.**

### IF PROBLEMS OCCUR:

Ask help from the infosecretary of Physicum or contact with our Computer Helpdesk.

737 5500 (5500)

[arvutiabi@ut.ee](mailto:arvutiabi@ut.ee)

[www.it.ut.ee](http://www.it.ut.ee)

