

NOORUSE 1-519 RUUMITEHNIKA JUHEND

PROJEKTORI KASUTAMINE:

Ühenda lauapeal olev **HDMI-** või **VGA-kaabel** sülearvutiga.



HDMI kaabel

VGA kaabel koos audioühendusega

Lülita puldi **roheline** nupuga projektor sisse



Muid juhtmeid mitte lahti ühendada!!!

Sisendite signaale on võimalik vahetada vajutades projektori puldi nuppu **INPUT**.



Kui sülearvuti pilt mõne aja möödudes pärast nupuvajutust projektorisse ei ilmu, proovida klahvikombinatsiooni:



Projektor tuleb pärast kasutamist kindlasti välja lülitada, vajutades sedasama roheline nuppu, mis käivitamisel!

PROBLEEMIDE TEKKIMISEL:

Ühendust võtta Tartu Ülikooli Arvutiabiga.

737 5500 (5500)

arvutiabi@ut.ee

www.it.ut.ee



NOORUSE 1-519 EQUIPMENT USAGE INSTRUCTIONS

USING THE PROJECTOR:

Use the **HDMI** or **VGA** cable or on the table to connect your laptop to the projector.



HDMI cable



VGA cable with audio jack

Press the **green** button on the remote to turn on the projector.



Do not reorganize any other cables!!!

To choose from different devices use the **INPUT** button on the remote.



If the laptop screen does not appear on the projector after pressing this button and waiting a while, press:



After using the projector be sure to turn it off by pressing the same green button as used to turn the projector on.

IF PROBLEMS OCCUR:

Contact with our Computer Helpdesk.

737 5500 (5500)

arvutiabi@ut.ee

www.it.ut.ee

