

NOORUSE 1-615 RUUMITEHNIKA JUHEND

PROJEKTORI KASUTAMINE:

Ühenda lauapeal olev **HDMI-kaabel** sülearvutiga. Ennem tuleb veenduda, et sülearvutil on **HDMI port** olemas.



HDMI-kaabel

Lülita puldi **roheline** nupuga projektor sisse.



Kui arvuti pilt mõne aja möödudes pärast nupuvajutust projektorisse ei ilmu, proovida klahvikombinatsiooni:



Projektor tuleb pärast kasutamist kindlasti välja lülitada, vajutades sedasama **rohelist** nuppu, mis käivitamisel!

PROBLEEMIDE TEKKIMISEL:

Ühendust võtta Tartu Ülikooli Arvutiabiga.

737 5500 (5500)

arvutiabi@ut.ee

www.it.ut.ee



NOORUSE 1-615 EQUIPMENT USAGE INSTRUCTIONS

USING THE PROJECTOR:

Connect the **HDMI cable** to the laptop. Make sure your laptop has **HDMI port**.



HDMI-cable

Press the **green** button on the remote to turn on the projector.



If the computer screen does not appear on the projector after pressing this button and waiting a while, press:



After using the projector be sure to turn it off by pressing the same **green** button as used to turn the projector on.

IF PROBLEMS OCCUR:

Contact with our Computer Helpdesk.

737 5500 (5500)

arvutiabi@ut.ee

www.it.ut.ee

