

Mitel 6863 SIP Phone for MX-ONE

QUICK REFERENCE GUIDE



NOTICE

The information contained in this document is believed to be accurate in all respects but is not warranted by Mitel Networks[™] Corporation (MITEL®). Mitel makes no warranty of any kind with regards to this material, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose. The information is subject to change without notice and should not be construed in any way as a commitment by Mitel or any of its affiliates or subsidiaries. Mitel and its affiliates and subsidiaries assume no responsibility for any errors or omissions in this document. Revisions of this document or new editions of it may be issued to incorporate such changes.

No part of this document can be reproduced or transmitted in any form or by any means - electronic or mechanical - for any purpose without written permission from Mitel Networks Corporation.

Trademarks

Mitel® is a registered trademark of Mitel Networks Corporation.

All trademarks mentioned in this document are the property of their respective owners, including Mitel Networks Corporation. All rights reserved.

*, TM Trademark of Mitel Networks Corporation ©Copyright 2015, Mitel Networks Corporation All rights reserved

Notice to European customers:

The CE marking affixed to Mitel products indicates conformance to the R&TTE directive 99/05/EC (Radio and Telecommunications Terminal Equipment Directive). For a copy of the original signed Declaration (in full conformance with EN45014), please contact your Mitel office or Sales partner.

 ϵ

Safety Instructions

Save these instructions.

Read these safety instructions before use!

Note: When using your telephone or connected equipment, the following basic safety precautions should always be followed to reduce risk of fire, electrical shock and other personal injury.

- Follow instructions in the equipment's user guide or other documentation.
- Always install equipment in a location and environment for which it is designed.
- For mains powered telephones: Only operate with the mains power voltage indicated. If you are uncertain of the type of power supplied to the building, consult property management or your local power company.
- For mains powered telephones: Avoid placing the telephone's power cable where it can be exposed to mechanical pressure as this may damage the cable. If the power supply cord or plug is damaged, disconnect the product and contact qualified service personnel.
- Do not make any changes or modifications to equipment without seeking approval from the party responsible for compliance. Unauthorized changes or modifications could void the user's authority to operate the equipment.
- Do not use the telephone to report a gas leak in the vicinity of the leak.
- Do not spill liquid of any kind on the product or use the equipment near water, for example, near a bathtub, washbowl, and kitchen sink, in a wet basement or near a swimming pool.
- Do not insert any object into equipment slots that is not part of the product or auxiliary product.
- Do not disassemble the product. Contact a qualified service agency when service or repair work is required.
- Do not use a telephone (other than cordless type during an electrical storm).

Disposal of the product

Your product should not be placed in municipal waste. Please check local regulations for disposal of electronic products.

Power Adapters

The phone can be powered either from a 48 V DC power adapter (sold separately) or via the network PoE according to IEEE 802.3af.

6865i: Powered either from a 48 V AC/DC power adapter or via PoE according to IEEE 802.3af

Recommended power adapters

- D6700-0131-48-20 (Universal)
- 87-00012AAA-A (Europe)
- 87-00013AAA-A (North America)


4 *MX-ONE – Mitel 6863*

Mitel 6863 Quick Reference Guide

This Quick Reference Guide includes short descriptions on how to use the basic features of the IP phone Mitel 6863 when used with a MX-ONE system. More features and technical requirements are available in the User Guide.

The complete User Guide is available in electronic format on www.mitel.com

Read the safety instructions before use!



- 6863i Handset
- High Quality Speakerphone
- Message Waiting Lamp
- Navigation/Select Keys
- Options Key
- Goodbye Key
- Hold Key
- Line/Call Appearance Keys
- Keypad
- Mute Key
- Volume Control
- Speaker Key d
- LCD Screen
- Callers list
- Redial Key
- Transfer

Display screen

The display comprises three information lines.

In idle -Extension number

> -E.g. the number of missed incoming calls, personal number profile, absence or diversion.

-The date and time

During a -The correspondent's name and/or call

number

-An icon showing the call status

-The time since the start of the call

In the menus In the options menus, lists and during programming, the screen guides the user in his or her choices and settings.

MX-ONE - Mitel 6863

Log On

Display Information

Navigating the menu: To reach the options menu, press the following key:

Press ▼ and ▲ to scroll the menu. Press ◀ to exit and ▶ to enter the option.

Log On

Log on: Enter the extension number and press ∇ for Enter.

If a PIN code is initiated in MX-ONE, there will be a Password prompt. Enter your PIN code as Password and press ♥ for Enter.

If you do not know your extension number or your PIN, contact your system administrator.

Your extension number and name are shown in the display when the log on is successful.

Change of PIN code

You can change the PIN code used for logging on to the telephony system.

Change the PIN code: Enter *74*old PIN*new PIN#

A text message on the display confirms if the change was successful

Incoming Calls

Answer Calls

Answer:



Press 👨

Reject call:

Picking up calls

You can answer a call from another phone:

Incoming Calls

Answer Calls (Continued)

Call pick-up:

Extension number. Press

Dial and wait for a busy tone and press **8**

France: 0

New Zealand: 4

Sweden: 6

Finland and Sweden: *0# U.S.A. and Canada: *59#

Missed Calls

Check missed calls: Press the softkey for callers list.

Missed calls are indicated in the list by a phone symbol with the handset kept on.

Outgoing Calls

Make Calls

To make a call in discreet mode (without loudspeaker), just lift the handset before or after dialling the number.

Internal calls: Extension number. Press

Dial

External calls: External access code +

External number. Press Dial

Dial by Contact see Redial Key (Redial Key):

Calling from the call

Press or the Callers list

key. Scroll to the record in the list

sts: **key**. Scroll to the record in the list and press or

Redial last external number:

Finland and Sweden: **0

Callback

The busy extension calls back when free

Order:

Press 6

France, New Zealand and Sweden: 5

Cancel all callbacks:

#37# Press Dial

Cancel single callback: #37* extension number #

U.S.A. and Canada: #6*

Call Waiting

A call waiting signal is sent to the busy number

Press 5. If you hear a ring tone, Order:

keep the handset off hook.

France and New Zealand: 6

Cancel call waiting:



Call Waiting signal is indicated on line 2 () during an ongoing call on line 1.

Answer:



Intrusion

Intrude a busy extension to ask the party to hang up.

Activate: Press 4

France, New Zealand and Sweden: 8

Bypass

Bypass Diversion (e.g. Follow-me) on a specific extension.

Activate:



U.S.A. and Canada: *1*...

During Calls

Put on Hold

Ongoing call:

Press 🚱

Resume a call-

Press 🕻 again

Inquiry

Ongoing call: Press the Transfer key, enter the

number to the 3rd party. Press L2

and wait for answer.

Switch between calls: Press the line key that holds the call

you want to retrieve.

Conference

Ongoing call: Press the skortcut key for Transfer,

dial the number to the 3rd party, press a free **Line** key and after

answer press 3

Repeat to add more participants.

Transfer

Ongoing call: Press the softkey for Transfer, enter

the number to the 3rd party. Press L2 and then press the Transfer key again (either before or after answer) to transfer the call

Encrypted call

Ongoing call: When a padlock is shown in the

display, the speech is encrypted to and from the phone.

Diversion

Follow-me

Order Follow-me and External Follow-me

Order Follow-me: *21* new answering position

number#

Press **Dial**

Canada, United Kingdom and U.S.A.: *2*...

If succesful, a diversion text will be

shown in the display.

Diversion

Follow-me(Continued)

Order external Follow-me:

*22# External line access code +
External number#

Press **Dial**

If succesful, a diversion text will be shown in the display.

Cancel Follow-me and External Follow-me

Cancel Follow-me: #21#

Press **Dial**

Any diversion text will be removed

Cancel External Follow-me:

#22#

Press **Dial**

Any diversion text will be removed

Group Do Not Disturb

From an extension with a certain class of service it is possible to set do not disturb for a group of extensions. Calls to the extensions in the group will not be indicated.

Press **Dial**.

distrurb:

Germany, South Africa, North America: *28*group number#

Cancel:

A # 25*group number #

Press **Dial**

Germany, South Africa, North America: **#28*group number**#

Presence Information

Select absence reason with return date/time:

*23*Absence reason*Date/

Time#

Press **Dial**

The absence reason and the format of time and date are site dependent. Contact the system administrator for information

Canada and U.S.A.: *24*...

Select absence reason without return date/time:

*23*Absence reason#

Press **Dial**

The absence reason is site

dependent. Contact the system administrator for information

Canada and U.S.A.: *24*...

Cancel: #23#

Press **Dial**

Canada and U.S.A.: #24#

Personal Number

A number of answering positions can be defined in a personal number profile. Up to 5 profiles can be defined. You select the wanted profile from your telephone.

When somebody calls your normal office phone number the call will be announced on the telephones defined in your active profile.

The profiles can be defined by user via CMG Office Web or by the the system administator.

Personal Number

Order or change profile from own extension:

Press **Dial**

n=the desired profile number

#profile number is shown on the top row in the display, e.g. #1

Deactivate:

210*n#

Press **Dial**

#profile number is removed from the top row in the display.

Advanced Features

Account Code

New external call:

*61*Account code#

external number.

Norway and Finland: *71*...

Ongoing external call: Press 🚱

Press a free **Line** key and Dial * 61 * Account code # and

wait for confirmation tone for valid code.

Clear the line used for entering the account code.

Press the **line** key that holds the

call.

Norway and Finland: *71*...

Authorization Code

Common Authorization Code

Dialing:

72 Authorization code #

Press Dial and wait for verification tone. Dial external

numher

Canada and U.S.A: *6*... Austria, Germany, The Netherlands: *75*

Authorization Code (Continued)

73 Authorization code # Locking extension:

Press Dial

Canada and U.S.A: *71*...

Unlocking extension: #73* Authorization code #

Press Dial

Individual Authorization Code

75 Authorization code # Dialing from own

> Press Dial and wait for verification tone. Dial external

number.

Austria, Germany, The Netherlands: *72*...

Dialing from other extension:

extension:

縫 *75* Authorization code *own extension number# Press

Dial and wait for verification tone.

Dial external number.

Austria, Germany, The Netherlands: *72*...

Locking extension:

*76*Authorization code #

7

Press Dial

Unlocking extension: #76*Authorization code #

Press Dial

General Deactivation #001#

Deactivate all activated features: Press Dial

U.S.A. and Canada: *0#

Call Park Pool

You can park a call and transfer the call at a specific directory number (also called Call Park Pool) and any extension can pick up the call. If the call is not picked up within a few minutes, the call will recall your extension.

Transfer the call to the call park pool:

You have an active call. Press the **Transfer** key to put the call on hold. Dial the number to the call park pool. Note the number (here called B-number) that shows up on the display. Press the **Transfer** key to transfer the call.

Inform the person that shall take the call that he/she shall pickup the call on number (B-number).

Pick up a call that is parked in the call park pool Dial the B-number that you received from your collegue. When you hear the busy tone press **8** to pick up the call

France: 0

New Zealand: 4

Sweden: 6

Voice Mail

Messages/Voice Mail

A voice mail system may have been set up by the system administrator. Contact the system administrator to get the number to the voice mail system.

Call voice mail system *Dial the voice mail system number* (e.g. record greeting announcement):

Listen to received messages:

The message waiting lamp is slowly blinking when there is a pending message.

*32# Press **Dial** to listen to it.

Settings in the Telephone

Volume

Adjust the listening *Press* volume of the:





- Handset
- Headset
- Ringer
- Hands-free

Mute

Mute microphone during call:

Press 🕦

during call:
Silent ringing: Press

Press several times until the text "Ringer volume is off" is

Note: The ring signal is switched off permanently

Display Language

Change display language:

Preferences > Language > Screen Language

Enter *08*n# to inform the sytem about the language

Press Dial

n = language number. Contact the system administrator.

Change keypad characters:

Preferences >
Language > Input Language

Time and Date

Set time format:

Preferences > Time
and Date > Time Format

Set date format:

Preferences > Time and Date > Date Format

Directory (Contacts)

Local Directory

The placing of the softkeys relevant for the local directory function are:

Save (top softkey)

Delete (second softkey from the top)

Local Directory (third softkey from the top)

Enter the local

Press Local Directory

directory:

or **Local Directory**

Exit the local directory:

Search for a Contact: In the directory scroll down to the first contact and press the first

letter of the name you want to

Call from local directory:

In the directory, scroll to the contact

and press or

Add a contact to the Local Directory + Save, then

local directory:

follow instructions

Delete contact from

 $In \, the \, directory, scroll \, to \, the \, contact$ and press **Delete** (twice)

local directory:

from the local directory:

Edit contact In the directory, scroll to the contact

and press **d** to erase.

Web Interface

Using the Web Interface

Find out the phone's IP address: Addresses

0 Phone Status > IP&MAC

Enter the IP address into the address field in the web browser in your PC

Logon: Open a web browser on your PC and

enter the phone's IP address in the

address field. Enter userid: user

password: blank is the default

password

Mitel 6863 Quick Reference Guide

10 *MX-ONE – Mitel 6863*

FCC Statement (U.S.A.)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

HAC (Hearing Aid Compatible)

MX-ONE – Mitel 6863

MX-ONE – Mitel 6863 12